

Silveridge PickleBall Club



Pickleball Machine Instructions

1. Court Number 1 is reserved for ball machine use because that is where the plugin is located.
2. The Ball machine must be signed out on SignUpGenius.
3. ONLY paid members are allowed to use ball machine.
4. The Pickleball Tutor optimum position for most shots is 1-2 feet behind the baseline. Raising and lowering creates different delivery.
5. Gently raise the ball hopper sides and fill with balls provided.
6. Plug in ball machine. Adjust ball speed and elevation settings together. When adjusting the elevation switch, make the final adjustment up, this will lock the elevation into the position.
7. DO NOT lower the elevation below the "1" on the sticker.
8. The oscillation feature will direct shots randomly across the court. 2-Line Oscillation will alternate shots to two positions
9. Pushing the "ON" position begins a start-up time delay period of 10 seconds. When readjusting, turn machine off then reset. This will also reset the delay feature.
10. Ball Speed: 1 low – 10 high. Start with average to minimum speed.
11. Ball feed: 1 slow – 10 fast. Start with average to minimum feed.
12. IMPORTANT: always make sure machine is off when adjusting. **DO NOT stand in front of delivery opening.**
13. UNPLUG machine to dislodge jammed balls or any other maintenance that is required.
14. If there is a problem with the operation of the machine, IMMEDIATELY turn off power and report the issue to a Club Executive member.
15. If not comfortable using the machine for the first time, contact a Club Executive member for help.
16. Ensure that all balls are removed, and hopper sides are down prior to transporting machine.
17. After being the last person/persons to use the machine assure that everything is put back in the storage container and LOCKED.

See you on the court!